

# CSM HOW TO



## STAINLESS STEEL CAB/COWL PANELS

### THIS MONTH:

Installation of P/N-01-09123002 stainless steel cab/cowl on a 389 Peterbilt.

NOTE: This month's CSM How To is a great project for truckers who like to customize their ride!



**STEP: 1** Prefit cab/cowl panel to cab, note leading edge of panel with any areas that need notched out to accomodate OEM brackets.



**STEP: 2** Using a die grinder or plasma cutter, notch out areas as marked for a perfect fit.



**STEP: 3** On top flange of cab/cowl panel, lay out evenly spaced marks on approximately 8" centers for mounting holes.



**STEP: 4** Using a drill with a 1/4" bit, drill each hole on cab/cowl panel as marked.



**STEP: 5** Hold cab/cowl panel up under cab, using a scribe, mark holes to be drilled on bottom of cab.



**STEP: 6** Using same drill and 1/4" bit, drill marked holes in cab.



**STEP: 7** Mount using 1/4" x 1" bolts, washers, and nylock nuts to fasten.



**STEP: 8** Drill and mount bottom of front of cowl panel, using bolts from factory splash apron.

**STEP: 9** WIPE DOWN AND ENJOY!!!

For this project, we used stainless steel cab/cowl panels on a 389 Peterbilt part P/N-01-09123002. 4 State Trucks and The Chrome Shop Mafia stock a great selection of many types of cab-cowls. For all types of truck parts and accessories call **888.875.7787** or visit [www.4statetrucks.com](http://www.4statetrucks.com) to view the entire selection.

BRYAN 'BOSSMAN' MARTIN OPERATES 4 STATE TRUCKS - 'HOME OF THE CHROME SHOP MAFIA' IN JOPLIN, MO AND HAS BEEN PROVIDING QUALITY PARTS TO TRUCKERS FOR OVER 20 YEARS!

**PARTS • CHROME • ACCESSORIES**  
**FABRICATION • INSTALLATION • SALVAGE**  
[WWW.4STATETRUCKS.COM](http://WWW.4STATETRUCKS.COM) [WWW.CHROMESHOPMAFIA.COM](http://WWW.CHROMESHOPMAFIA.COM)