

CSM "HOW TO"



POLISHED S/S TANK STRAPS

THIS MONTH:

Installation of #CSMKW2450S
6" wide polished s/s tank
straps on Kenworth

NOTE: This month's CSM How To
is a great project for truckers who
like to customize their ride!



STEP: 1 Loosen bolts to remove factory
straps.



STEP: 2 Wipe down tank to get rid of debris
and gravel.



STEP: 3 Put a protective barrier between
new straps and tank (thin rubber,
or 4" nylon strap works well).



STEP: 4 Slide in top of new strap first and
slide bolt through eye of it.



STEP: 5 Slide "t" bolt through bottom
bracket.



STEP: 6 Tighten snug both top and
bottom bolts – CAUTION: DO
NOT overtighten lower tee bolt!

STEP: 7 Peel plastic and wipe down
with glass cleaner and microfiber
towel – enjoy!!!

For this project we used 6" wide polished s/s tank straps #CSMKW2450S. 4 State Trucks and The Chrome Shop Mafia stock a great selection of many types of tank straps. For all types of truck parts and accessories call **888.875.7787** or visit www.4statetrucks.com to view the entire selection.

BRYAN 'BOSSMAN' MARTIN OPERATES 4 STATE TRUCKS –
'HOME OF THE CHROME SHOP MAFIA' IN JOPLIN, MO AND HAS BEEN PROVIDING
QUALITY PARTS TO TRUCKERS FOR OVER 20 YEARS!

Log on to www.chromeshopmafia.com for updates on
the **Guilty By Association Truck Show & Customer Expo**
October 9 & 10, 2009.

PARTS • CHROME • ACCESSORIES
FABRICATION • INSTALLATION • SALVAGE
WWW.4STATETRUCKS.COM • WWW.CHROMESHOPMAFIA.COM